


**Assembly instructions
for an incomplete machine**

DUNGS HeatEngine[®]



Designation:

DUNGS HeatEngine[®]
HEPM-P (HeatEngine PreMix Point-style)
HEPM-L (HeatEngine PreMix Line-style)

Date of issue:

2025-12-15

Publication version:

Version 2

Identification of the machine:

see drawing (appendix)

Table of Content

1	Introduction and purpose of these instructions	4
2	General safety instructions	5
3	System overview	7
3.1	Functional description	7
3.2	Intended use and misuse	9
3.3	Technical data	10
3.4	Function of the control unit	12
4	Transport and storage	13
5	Installation and commissioning	13
5.1	Scope of delivery	13
5.2	Integration into the machine	14
5.3	Checking the Installation	16
5.4	Commissioning	17
6	Manufacturer settings	20
7	Operation	22
8	Product and capacity changes	22
9	Maintenance and servicing	22
9.1	Maintenance and servicing of the burner head HEPM-BH	23
9.2	Replacement parts for burner heads HEPM-BH	24
9.2.1	Point style burner heads up to 40 kW	25
9.2.2	Point style burner head from 60 kW	26
9.2.3	Line style burner heads	27
9.3	Replacement instructions	28
9.3.1	Replacement of the electrode(s)	28
9.3.2	Replacement of the flame tube	30
9.3.3	Replacement of the burner pad	31
10	Cleaning	32
11	Malfunctions	33
12	Decommissioning and disposal	33
13	Documents and drawings	34

List of Figures

Table 1: Standard versions of the HeatEngine	8
Table 2: Flame length of the standard versions	11
Table 3: Standard values for setting the main volume throttle.....	21
Table 4: Service life of the components.....	22
Table 5: Mapping between standard HeatEngine and burner head	24
Table 6: Replacement sets for burner heads D040 and D060	25
Table 7: Replacement sets for burner heads D070, D098 and D130	26
Table 8: Replacement sets for burner heads E200, E450 and E900.....	27
Figure 1: P&ID diagram of the HeatEngine.....	7
Figure 2: Type code of the HeatEngine	10
Figure 3: Mounting flange and seals of the HeatEngine.....	14
Figure 4: HeatEngine in process chamber with outer and inner lining/insulation (line-style burner system)	15
Figure 5: HeatEngine in process chamber with outer and inner lining/insulation (point-style burner system)	15
Figure 6: Compensation hose on the MBC.....	17
Figure 7: MBC Connections.....	18
Figure 8: Diagram for setting the main volume throttle.....	20
Figure 9: Height measuring of main volume throttle.....	21
Figure 10: Positioning of the ignition electrode	23
Figure 11: Nomenclature of the burner heads HEPM-BH	24
Figure 12: Structure burner head HEPM-BH-P-D040	25
Figure 13: Structure of burner head HEPM-BH-P-D098	26
Figure 14: Structure of burner head HEPM-BH-L-E200	27

1 Introduction and purpose of these instructions

The DUNGS HeatEngine burner system is an incomplete machine within the meaning of the Machinery Directive for installation in a thermoprocessing system as a higher-level machine. This document corresponds to assembly instructions in accordance with Annex VI of the Machinery Directive or Annex XI of the Machinery Regulation and contains a general description as well as the necessary information for installation and integration into the control system of the higher-level machine (thermoprocessing system). It also contains instructions for use and maintenance.

If the information contained in these instructions is not sufficient, please get in touch with your contact at Karl Dungs GmbH & Co. KG, the DUNGS Support Centre (+49 7181 804-804, supportcenter@dungs.com) or DUNGS Global Service (+49 7181 804-0, servicecenter@dungs.com). Contact our American colleagues for US-applications (+1-763-582-1700, info@karldungsusa.com).

You can also find more information about your product at www.dungs.com.

Name and address of the manufacturer:







Karl Dungs GmbH & Co
KG Karl-Dungs-Platz 1
73660 Urbach Germany








Current version of this document: <https://www.dungs.com/en/product/dungsheatengine>



You can find further information about the product on our website. As there are versions for both hydrogen and natural gas/propane, there are two separate documentations available. Please ensure that you always use the correct instructions for your version

2 General safety instructions

	<p>The basic prerequisite for safe handling and trouble-free operation of the HeatEngine is the knowledge of the basic safety instructions and safety regulations. These instructions and the descriptions of the devices installed in the HeatEngine contain the most important instructions for operating the HeatEngine safely. These instructions, in particular the safety instructions, must be observed by all people who operate, run and maintain the HeatEngine. In addition, the rules and regulations for accident prevention applicable at the respective place of use must be observed.</p>
<p>Note</p>	
	<p>Before initial commissioning and before working on the HeatEngine, the instructions in this manual and the operating and installation instructions for the devices and components installed in the HeatEngine must be observed. Maintenance and operating personnel must be trained accordingly.</p>
<p>Warning</p>	
	<p>Before commissioning this DUNGS HeatEngine, the procedure must be agreed with the system operator and/or the installer. Improper adjustment, modification, operation and maintenance can lead to property damage and personal injury, possibly resulting in death.</p>
<p>Danger</p>	
	<p>All work on the HeatEngine (e.g. maintenance and repair work) may only be carried out by qualified, expert personnel. DUNGS service personnel and our authorized specialist dealers fulfil this requirement.</p>
<p>Danger</p>	
	<p>The HeatEngine is a burner system in which gas and air are mixed and burnt in a controlled manner as a combustible premix. Incorrect and/or improper use, installation, control and maintenance can lead to fire or explosion.</p> <p>Check all seals in the direction of flow for leaks using foam-forming agents.</p>
<p>Note</p>	
	<p>The system is intended for installation in a higher-level machine that provides the necessary protection against accidental contact and protection against foreign bodies and water. Operating the system without appropriate protection is considered improper use.</p>

Danger	
	<p>During ignition, a high-voltage spark of > 7kV is generated via the ignition electrode. The product and the associated electrical equipment must be de-energized before maintenance/repair.</p> <p>Before starting work, check that the system is de-energized. Work and troubleshooting on the electrical part of the HeatEngine may only be carried out by trained specialists. The accident prevention regulations and relevant standards must be observed.</p>
Warning	
	<p>The surfaces of the burner housing can become very hot during operation. Beware of unintentional contact with hot surfaces. The HeatEngine must be completely cooled down before maintenance/maintenance work can be carried out. To ensure sufficient cooling, the HeatEngine must be installed in a well-ventilated location.</p>
Warning	
	<p>Regular maintenance of the HeatEngine is necessary. Safety devices must be checked for proper functioning once a year or after 10,000 operating hours at the latest and repaired or replaced if necessary.</p>
Danger	
	<p>Sufficient pressure or cross ventilation must be provided at the installation site of the HeatEngine to prevent the formation of an explosive atmosphere in the event of a fault.</p>
Note	
	<p>If extraordinary noise exposure should occur during commissioning and maintenance work, it is advisable to wear personal protective equipment (hearing protection).</p>
Danger	
	<p>When working on the gas-carrying pipe system of the HeatEngine and the components installed in it, the gas supply must be safely shut off before starting work.</p>
Danger	
	<p>The system includes a combustion air fan with rotating parts. When working on the system/machine, wait until all parts have come to a standstill. Wear appropriate clothing or keep your distance during operation</p>

3 System overview

3.1 Functional description

The HeatEngine is a premix surface burner system for generating heat in machines for thermal processes. The system has a modular design and fulfils the requirements of the relevant standards for thermal process plants (ISO 13577-2).

For NFPA 86:2023 some adaptations are needed. The NFPA version of the P&ID diagram is shown in *Appendix 2*.




Figure 1: P&ID diagram of the HeatEngine

Fehler! Verweisquelle konnte nicht gefunden werden. shows the P&ID diagram of the HeatEngine (see *Appendix 2*) and illustrates the individual modules of the HeatEngine and their functions. The main modules are:

- **M1** Gas connection with ball valve (1.1) as main shut-off valve and connection hose (1.2) if necessary
- **M2** Gas train with filter (2.1), pressure gauge (2.2.1), minimum gas pressure switch (2.3.1) and GasMultiBloc MBC (2.3) as a control and safety combination. The MBC combination control (2.3) combines the function of two automatic shut-off valves and a proportional/zero pressure regulator for mixture control. The Module 2 is different for NFPA 86:2023 versions. E.g. test ports, a maximum gas pressure switch and a second ball valve are added (see NFPA 86 P&ID diagram in *Appendix 2*). The following limitations and changes are required as well:
 - Above 44 kW / 150 kBTU/H visual indicators are needed. The use of a MBC is not possible, instead a DMV with FRNG (including visual indicator) is used.
 - From 117 kW / 400 kBTU/H besides the visual indicator one proof of closure is needed. The use of a MBC is not possible, instead a DMV with FRNG (including Proof of closure) is used.

- **M3** Combustion air fan (radial fan, 3.1) with intake housing and WhirlWind gas/air mixer (3.2) for zero pressure operation on the gas inlet. An air filter (3.2.3) is fitted to the intake opening and the negative pressure in the intake housing is connected to the MBC controller (2.3) as a pressure compensation for the power-dependent pressure losses
- **M4** Connector with pressure switch (2.5.1) for monitoring the air/gas mixture pressure
- **M5** Surface burner head (5.1) in point-style or line-style geometry
- **M6** Burner control unit MPA with parameterization and ignition transformer
- **M7** Electrical wiring and assembly

The burner system is supplied pre-assembled. Depending on the order, however, the M6 module (burner control unit and ignition transformer) can be supplied separately to support integration into the higher-level machine on site. The modular design enables customization to the individual higher-level machine without fundamentally changing the function. The burner head geometry and burner output must be selected according to the requirements. The modules and their possible combinations are illustrated graphically in the appendix using the poster (see *Appendix 1*).

Available standard versions of the DUNGS HeatEngine are:

Type	Designation	Item no.	Burner head geometry	Burner output ¹⁾	Gas connection
HEPM-P025	HEPM-P025/NG-EU-S-IO-1W-E	294440	Point Ø 40 mm ^[OBJ] Point Ø 1.5"	5 - 25 kW 15 / 85 kBTU/H	Rp ½ ½" NPT
HEPM-P040	HEPM-P040/NG-EU-S-IO-1W-E	294441	Point Ø 60 mm Point Ø 2.4"	7 - 40 kW 25 / 140 kBTU/H	Rp ½ ½" NPT
HEPM-P060	HEPM-P065/NG-EU-S-IO-1W-E	294442	Point Ø 70 mm Point Ø 2.75"	8 - 65 kW 30 / 225 kBTU/H	Rp ½ ½" NPT
HEPM-P090	HEPM-P090/NG-EU-S-IO-1W-E	294443	Point Ø 98 mm Point Ø 4"	11 - 90 kW 50 / 315 kBTU/H	Rp ¾ ¾" NPT
HEPM-P140	HEPM-P140/NG-EU-S-IO-1W-E	294444	Point Ø 130 mm Point Ø 5.1"	14 - 140 kW 60 / 500 kBTU/H	Rp ¾ ¾" NPT
HEPM-L025	HEPM-L025/NG-EU-S-IO-1W-E	294445	Line 200 mm Line 8"	5 - 25 kW 15 / 85 kBTU/H	Rp ½ ½" NPT
HEPM-L065	HEPM-L065/NG-EU-S-IO-1W-E	294446	Line 440 mm ^[OBJ] Line 17.3"	8 - 65 kW 30 / 225 kBTU/H	Rp ½ ½" NPT
HEPM-L140	HEPM-L140/NG-EU-S-IO-1W-E	304896	Line 880 mm Line 34.6"	14 - 140 kW 60 / 500 kBTU/H	Rp ¾ ¾" NPT

Table 1: Standard versions of the HeatEngine

Details of the equipment and burner head geometry as well as any technical data deviating from the standard can be found in the order-specific drawing and parts list (see appendix) for the system. The precise execution of the system varies depending on applicable standards and needs for the application. The detailed design can be read from the drawing using the type code. The type code is explained under *3.3 Technical data*.

We reserve the right to make modifications in the interest of technical development.

¹ Burner output in relation to lower calorific value and at neutral back pressure

3.2 Intended use and misuse

The HeatEngine is designed for installation in industrial thermoprocessing systems in accordance with ISO 13577-2. The product may only be operated in the enclosure intended for this purpose. For the installation and operation of the HeatEngine in a higher-level machine, the relevant application standards and guidelines must be observed, e.g. ISO 13577-2 or NFPA 86:2023. Outdoor operation in a production environment is only permitted with suitable protective measures. The product is intended for use in closed, dry rooms in an industrial environment.

The HeatEngine is a burner system that provides an adequate mixture of gas and air for the subsequent process. It is designed for natural gas (H/L) and LPG/propane (<5% butane)-

Any use of the HeatEngine other than that described here is not permitted. The following risks are possible in the event of misuse:

- The HeatEngine is only safe to operate if it is used as intended
- Failure to observe the instructions may result in personal injury or property damage, financial loss or environmental damage
- In the event of incorrect operation or misuse, there is a risk to life and limb of the operator as well as to the HeatEngine and other property

Warranty and liability

Warranty and liability claims for personal injury and damage to property are excluded if they are attributable to one or more of the following causes:

- improper use of the HeatEngine
- Improper transport, commissioning, operation and maintenance
- Failure to observe the instructions in the manual regarding transport, commissioning, operation, maintenance and repair
- Operating the HeatEngine with defective or non-functional safety and protective devices
- Unauthorized structural changes to the HeatEngine
- Unauthorized changes, e.g. to the control pressure
- Non-compliance with the required maintenance cycles
- Use of unauthorized spare and wear parts

Only use original spare and wear parts. In the case of externally sourced parts, there is no guarantee that they are designed and manufactured to withstand the stress and ensure safety. An exception to this is if no other spare parts are available and the alternative has been previously accepted by DUNGS.

3.3 Technical data

Variants based on the type code

The exact design of the existing DUNGS HeatEngine can be defined through the type code (Figure 2). This indicates whether it is a point- or line-style burner head, the output of the burner system, the medium with which the system is operated and the region for which it was designed. It also includes the control unit, flame monitoring, wiring, voltage and, if required, a customized abbreviation with a sequential number.




Figure 2: Type code of the HeatEngine

Mechanical Data

	min.	max.
Pressure in the combustion chamber	-5 mbar -2" WC	+3 mbar +1.5" WC
Temperature in the combustion chamber	20 °C 68 °F	<ul style="list-style-type: none"> 450 °C downstream of the burner 300 °C upstream of the burner (incoming process air) 842 °F downstream of the burner 572 °F upstream of the burner (incoming process air)
Ambient temperature	-15 °C 5 °F	60 °C 140 °F
Gas pressure inlet	30 mbar 0.5 Psig	65 mbar (up to 65 kW variants) 100 mbar (from 90 kW variants) 0.95 Psig (up to 225 kBTU/H variants) 1.45 Psig (from 315 kBTU/H variants)

3.4 Function of the control unit

The burner system is controlled via the MPA burner control unit as an interface to the control unit of the higher-level machine. Details can be found in the circuit diagram (see appendix). A 3-point step control is used as a standard. Analog control with 0-10V or 4-20mA is also possible but must be specifically requested.

The following signal inputs and outputs are provided:

- Safety chain okay (emergency stop, overtemperature, machine-related safety limits)
- Heat request = switch on burner
- Increase performance.
- Reduce power.
- Interference suppression
- Operating message = Burner in operation
- Fault message

The combustion air fan and the automatic shut-off valves are controlled by the MPA burner control unit in accordance with the specified sequence. The speed of the fan for pre-purge and ignition as well as the maximum and minimum output are determined by the MPA parameters.

When heat is requested by the control system of the higher-level machine, the combustion air fan is started by the burner control system. The burner and the on-site combustion chamber are first pre-purged; the duration and fan output correspond to the MPA parameterization. Following the pre-purge, the blower output is reduced to the ignition output. To start the burner, the MPA opens the gas shut-off valves and activates the ignition transformer to ignite the gas-air mixture generated in the WhirlWind. The establishment of the flame is detected by the ionization electrode and the MPA burner control unit sends the operating signal to the control unit of the higher-level machine, which then takes over the power control.

During operation, the power is determined by the fan speed. The blower output is specified via a PWM signal. The air flow generates a negative pressure in the WhirlWind gas/air mixer, which sucks in the fuel gas through the Venturi effect (zero pressure control).

The gas volume is set to the required flow on the MBC at the integrated main volume throttle D and via the offset B (see *Figure 7*). The procedure for setting the main volume throttle on the MBC is described in ***Fehler! Verweisquelle konnte nicht gefunden werden. Fehler! Verweisquelle konnte nicht gefunden werden.*** and *6 Manufacturer settings*. Further information can be found in the MBC documentation.

When the heat request signal is switched off, the burner is switched off. The burner control unit de-energizes the automatic shut-off valves of the MBC and the valves close. The burner is then purged to remove the ignitable gas-air mixture from the burner and the on-site combustion chamber. The duration and blower output correspond to the MPA parameterization.

The presetting of the MBC and the standard parameters of the MPA allow quick and easy commissioning after installation and integration into the control system of the higher-level machine. A converter (order no. 301179) is required for analog control.

This is necessary as the standard combustion air fan can only interpret signals in the form of pulse width modulation. The converter is fed by the MPA and modulates a PWM signal using the analog input signal.

Note that this converter is not required if a 0-10VDC / 4-20mA controlled blower is used.

The structure of a 3-point step control and the analog control are shown as block diagrams (see *Appendix 3*). However, this diagram is only a general representation. For effective analog control, this must be detailed on a project-specific basis.

Alternatively, temperature control can be handled directly via a bus connection with Profibus and a programmable logic controller (PLC). In this case, the modulation degree (in %) of the PWM signal can be entered via input byte EB 6 of the MPA.

4 Transport and storage

Take care when storing and transporting the HeatEngine to the site. Handle the components with care. This also includes vibration-free transport.

Do not throw or drop the product. Observe the relevant regulations, e.g. accident prevention regulations. Only store the product in a dry and clean working environment. Only store the product within the permitted temperature range. Correct operation of the HeatEngine is only guaranteed if it is transported and stored correctly.

5 Installation and commissioning



5.1 Scope of delivery

The scope of delivery of the HeatEngine depends on the selection regarding *Module 7 - Wiring*. Ideally, a pre-assembled version should be ordered. In this case, the HeatEngine is delivered assembled and wired. The associated automatic burner control unit is also preset. The HeatEngine can be regarded as a plug & play system.

Alternatively, however, the HeatEngine can also be supplied with pre-wired loose individual parts or completely without cabling. In principle, every HeatEngine system - regardless of the choice of wiring - is supplied with the corresponding plugs and seals. When ordering a non-wired HeatEngine, the following electrical components can be supplied:

- Connectors for combustion air fan, electrodes, MBC and pressure switches
- Ignition cable (length e.g. 550 mm, 1000 mm or 1500 mm)
- Ionization cable (length e.g. 550 mm, 1000 mm or 1500 mm)
- Power supply cable for transformer

5.2 Integration into the machine

Note	
	Ensure a firm, stable substructure during installation. Reinforce if necessary!
Note	
	Pay attention to external EMC interference signals on site during installation! EMC interference signals can occur, for example, from motors with speed control via frequency converters.

The burner system is attached to the burner head via the mounting flange using six mounting screws. The mounting flange has two seals, see *Figure 3*. Information on the flange dimensions and the positions of the screw openings can be found in the drawing of the burner system.




Figure 3: Mounting flange and seals of the HeatEngine

The burner head is mounted on the housing of the process chamber using the mounting flange, position 1 in *Figure 3*. One seal, position 2 in *Figure 3*, is located on the transition piece between the burner head and combustion air fan and on the mounting flange. The second seal, position 3 in *Figure 3*, is placed between the mounting flange of the HeatEngine and the outer wall of the process chamber during installation. The external components such as cables and gas line must be protected from the heat. An outer lining, as shown in *Figure 4* on the left, only minimally increases the temperature resistance. With this variant, it is important that the mounting flange and screws are not insulated. With an inner lining, as shown in *Figure 4* on the right, it can withstand achieves a temperature of up to 450°C / 840°F.

The outer wall of the process chamber is represented by position 2 in *Figure 4*. Position 3 shows the outer insulation and position 4 the inner insulation. A sight glass must be provided to enable visual inspection of the flame in accordance with ISO 13577-2 and NFPA 86:2023. This is used for visual inspection of the flame pattern and for burner adjustment. In *Figure 4*, position 1 corresponds to the sight glass.




Figure 4: HeatEngine in process chamber with outer and inner lining/insulation (line-style burner system)

Installation via the mounting flange is equivalent for point-style and line-style burner heads. The difference based on the burner type lies in the positioning of the sight glass. The sight glass, which is required for visual inspection of the flame pattern, must always be aligned so that it is in line of sight with the pad. For line-style burner heads, it is sufficient to place a sight glass above the HeatEngine system, as shown in *Figure 4*. This is because the mounting wall is automatically perpendicular to the focal surface. With point-style burner heads, on the other hand, a wall adjacent to the mounting wall must be used. A sight glass placed perpendicular to the focal surface of a point-style burner head is shown in *Figure 5*.





Figure 5: HeatEngine in process chamber with outer and inner lining/insulation (point-style burner system)


In addition to installation of the burner head flange, the gas control line must be supported! This must be realized on site according to the possibilities of the higher-level machine.

When determining the installation position, ensure that the burner system is accessible for inspection and maintenance work. In accordance with ISO 13577-2 and NFPA 86:2023 it must be possible to visually inspect the flame (see flame pattern catalogue, *Appendix 4*).

When determining the installation location, it must be ensured that the combustion air fan can draw in sufficient clean, dust-free air and that the emissions produced during combustion are safely discharged. Sufficient openings must be provided in the higher-level machine for the air supply, through which clean ambient air can be drawn in.

Warning	
	Insufficient air supply represents a safety risk and must be ruled out.

After installing the burner system, establish a gas connection and check that the gas supply line is adequately dimensioned. The ball valve must be installed as a manually operated main shut-off valve in accordance with ISO 13577-2 or NFPA 86:2023 and must be easily accessible. The connection hose, if present, must be installed so that it is protected from damage.

Warning	
	Ensure that the gas pressure is secured on site. Excessive gas pressure (greater than the specified maximum inlet pressure) can lead to damage.

After the mechanical installation of the burner system in the higher-level machine, establish electrical connections and, if necessary, intermediate wiring in accordance with the circuit diagram (see appendix). Check the on-site electrical fuse protection.

After installation and before commissioning the DUNGS HeatEngine:

- a) Check power supply.
- b) Carry out an electrical function test.
- c) Check the gas system for leaks.
- d) Check the ventilation of the installation room.


Depending on the installation location of the higher-level machine, obtain the necessary authorizations in accordance with regional regulations before commissioning.

5.3 Checking the Installation

The installation and commissioning of the HeatEngine must be carried out by qualified, expert personnel. The relevant standards and regulations must be observed during installation and commissioning. Commissioning must be prepared as follows:

1. Check whether the higher-level machine is ready to start the burner system, e.g.
 - a) Burner not blocked
 - b) No flammable objects in front of the burner head (e.g. packaging waste, loose insulation, sticker, etc.)
 - c) Heat dissipation managed

- d) Exhaust gas removal ensured
- e) All required interlocks in order and integrated into the safety chain
2. Check the position of the electrodes in the burner head, see 9.1
3. Establish/check voltage and gas supply
4. Check the parameterization of the burner control unit MPA and adjust if necessary
 - a) Parameter 30 *Duration of pre-ventilation* is preset to a maximum value of approx. 1 hour as standard and can be shortened according to the machine configuration.
Note: In accordance with ISO 13577-2, 5 complete air changes are required. In accordance with NFPA 86:2023, 4 complete air changes are required.
 - b) Parameter 51 *Post-purge time* is preset to 6 seconds as standard to purge the burner itself and may need to be extended according to the machine configuration in order to also purge the combustion chamber and exhaust gas system.
 - c) Parameters 240 to 248 control the combustion air fan. They are preset with default values and can be adjusted to optimize the process.

Note	
	<p>The current fan speed can be displayed in the manual mode of the MPA. To switch to manual mode, press the “-” and “ENTER” buttons simultaneously. The fan speed is displayed in %.</p>

5. Checking the compensation hose:

In the standard version of the HeatEngine, the MBC acts as a constant pressure regulator. To compensate for influences such as a dirty air filter in the combustion air blower, a connection must be established between the MBC and the supply air collector. To do this, the MBC's vent (see *Figure 7*, vent E) must be connected to the blower pressure via a compensation hose. The attached hose can be seen in *Figure 6*. The maximum gas volume is adjusted to the air volume.





Figure 6: Compensation hose on the MBC

5.4 Commissioning


During commissioning, pay attention to the following:

- Unusual noise
- The shape and color of the burner flame (directly on the pad without oscillation or pulsation)
- Measure the power at the specified load levels (low, medium, and full load) using suitable measuring devices (e.g., gas meters)
- Document the settings of the burner system

Warning	
	<p>The system must be properly purged during initial commissioning or after work on the gas system.</p>

1. Open the gas ball valve and check the gas pressure on the pressure gauge
2. Check the setting of the gas pressure switch (item 2.3.1, Fig. 1) or set to
 - 25 mbar / 10"WC (approx. 80% of the minimum required inlet pressure of 30 mbar / 0.5 Psig)
3. Check setting of mixture pressure switch (item 2.5.1, Fig. 1) or set to 0.5 mbar / 0.2"WC
4. Switch on burner system (*heat request* signal)

The burner starts with a regular starting process with pre-purge, approaching the ignition position, ignition spark and flame formation. The fan output during pre-purge and ignition as well as the flame stabilization time is determined by MPA parameters 240 to 242.

Note	
	<p>Before the system was delivered, the MBC is preset so that the burner ignites. During initial commissioning or after work on the gas system, several start attempts may be necessary to fill the system with fuel.</p> <p>After three attempts to start without ignition, check the fuel supply, burner control settings, and spark position again.</p>

5. Run the burner to MAX (high load) and check the flame pattern visually using the flame pattern catalogue (see *Appendix 4*). If necessary, adjust the gas quantity at the main volume throttle **D** of the MBC (see *Figure 7*). The blower output is set by the MPA parameter 246 *Maximum speed* determined. The gas quantity can be determined by a gas meter, a gas counter or a measuring orifice in the gas supply line






Figure 7: MBC Connections

6. Set the burner to MIN (low load) and visually check the flame pattern (see flame pattern catalogue, *Appendix 4*). If necessary, adjust the gas quantity at offset screw **B** of the MBC. The blower output is determined by the MPA parameter 245 *Minimum speed*. The gas quantity can be determined by a gas meter, a gas counter or a measuring orifice in the gas supply line.

Note	
	<p>Only change the offset in very small steps of e.g. ¼ turn and make a note of this.</p> <p>The set offset can be determined by measuring the MBC outlet pressure at measuring port A. The gas pressure p_D corresponds to the offset when the black compensation hose is removed from the breathing port E.</p> <p>A slightly negative offset of approx. -0.05 to 0.0 mbar is recommended for a slightly increased lambda at low load.</p>

7. Switch back and forth several times between high load and low load, repeating steps 5 and 6. Finally, document the settings of the pressure switches, MPA parameters, position (length) of the main volume throttle, any changes made to the offset, controller outlet pressure (**measuring point 3**) at MAX and MIN and, if possible, gas volume flows MAX and MIN

Note	
	<p>The pad of the burner head should not glow during operation in order to avoid excessive wear. If the pad surface glows too much (significantly more than 50% glowing surface or 30% at low load), this can lead to thermal overload of the pad surface.</p>

At the end of commissioning, check the connections and closures for leaks using a foaming agent and retighten if necessary

6 Manufacturer settings

The HeatEngine flame pattern catalogue contains images for the correct setting of a point- and line-style burner system based on the flame pattern. The appearance of the flame varies depending on the combustion medium (*appendix 4*).

The setting values of the MBC and the pressure monitor can also be used as an aid. The min. pressure monitor on the MBC is set to 25 mbar / 10"WC as standard and the mixture pressure monitor on the burner connection piece is set to 0.5 mbar / 0.2"WC. The setting values for the main volume throttle, on the other hand, are not generally valid values, but merely reference points for the setting. This is because each system is different due to various tolerances.

As already described under *5.4 Commissioning*, there are two possible setting values for the MBC. Offset B should not be adjusted if possible, or only minimally if absolutely necessary and with documentation of the changes made.

The main volume throttle A, on the other hand, can and should be used to adjust the gas volume at the MBC. This changes the ratio of the air/gas mixture. The position and direction of rotation of the main volume throttle is shown in Figure 8.




Figure 8: Diagram for setting the main volume throttle

Guidance values for the setting of the main volume throttle have been identified from various laboratory tests. It should be emphasized once again that these are not absolute values. In addition to the product's own tolerances, the setting values depend on the capacity, fuel quality and gas pressure, among other parameters. Therefore, these values are given in the following table (*Table 3*) in addition to the design of the HeatEngine and the setting value of the main volume throttle.

Execution	Rated power [kW] / [kBTU/H] ⁴	Fuel	Throttle position [mm]
HEPM-P025	25 / 85	Natural gas (H)	15,3
		Propane	14,5
HEPM-P040	40 / 140	Natural gas (H)	16,3
		Propane	14,6
HEPM-P065	65 / 225	Natural gas (H)	16,7
		Propane	15,1
HEPM-P090	90 / 315	Natural gas (H)	14
		Propane	12,9
HEPM-P140	140 / 500	Natural gas (H)	19,1
		Propane	13,2
HEPM-L025	25 / 85	Natural gas (H)	15,5
		Propane	14,3
HEPM-L065	65 / 225	Natural gas (H)	16,2
		Propane	14,9
HEPM-L140	140 / 500	Natural gas (H)	16,2
		Propane	13,3

Table 3: Standard values for setting the main volume throttle




Figure 9: Height measuring of main volume throttle

⁴ The Output is specified in relation to the lower heating value (LHV)

7 Operation

The burner system is designed for fully automatic operation without supervision. The higher-level machine monitors the safety-related interlocks, switches the burner on and off according to the process requirements and controls the output by activating the corresponding inputs on the MPA burner control unit (see documentation). The MPA burner control unit monitors the gas and mixture pressure, controls the automatic shut-off valves and monitors the formation of the flame.

8 Product and capacity changes

It is necessary to replace safety-relevant components once they have reached the end of their service life. DUNGS recommends replacement in accordance with

Safety-relevant Component	Design-related service life		CEN standard
	Number of cycles	Time [years]	
Valve testing systems	250.000	10	EN 1643
Gas pressure switch	50.000	10	EN 1854
Air pressure switch	250.000	10	EN 1854
Low-gas switch	N/A	10	EN 1854
Combustion manager	250.000	10	EN 298 (gas) EN 230 (oil)
UV flame sensor ¹	N/A	10.000 Operating hours	-
Gas pressure regulators ¹	N/A	15	EN 88-1 EN 88-2
Gas valve with valve test systems ²	After recognised error		EN 1643
Gas valve without valve test systems ²	50.000-200.000 depending on the nominal diameter	10	EN 161
Gas-air composite systems	N/A	10	EN 88-1 EN 12067-2
¹ Decreasing operating characteristics due to ageing			
² Gas families II, III			
N/A not applicable			

Table 4:

Safety-relevant Component	Design-related service life		CEN standard
	Number of cycles	Time [years]	
Valve testing systems	250.000	10	EN 1643
Gas pressure switch	50.000	10	EN 1854
Air pressure switch	250.000	10	EN 1854
Low-gas switch	N/A	10	EN 1854
Combustion manager	250.000	10	EN 298 (gas) EN 230 (oil)
UV flame sensor ¹	N/A	10.000 Operating hours	-
Gas pressure regulators ¹	N/A	15	EN 88-1 EN 88-2
Gas valve with valve test systems ²	After recognised error		EN 1643
Gas valve without valve test systems ²	50.000-200.000 depending on the nominal diameter	10	EN 161

Gas-air composite systems	N/A	10	EN 88-1 EN 12067-2
¹ Decreasing operating characteristics due to ageing ² Gas families II, III N/A not applicable			

Table 4: Service life of the components

9 Maintenance and servicing

All maintenance and servicing work on the HeatEngine may only be carried out by qualified, expert personnel. DUNGS service personnel and our authorized specialist dealers fulfil this requirement.

Carry out regular annual inspections to maintain and ensure functional safety. Observe the instructions for the components used. Replace defective components from the DUNGS delivery program (pressure switch, MBC, etc. see details on the order-specific drawing). If a spare part is required, please contact your responsible sales engineer.

The minimum requirements for maintenance are as follows:

1. General condition check
2. Check condition of gas filter, air filter and wearing parts
3. Visual and functional inspection including the safety and control devices (pressure switch and GasMultiBloc MBC)
4. Check the safety-relevant components to ensure that they have reached their nominal service life.
5. Check fuel-carrying system components for leaks, corrosion, and signs of ageing.
6. Check the burner head with ignition and monitoring device, see chapter 9.1
7. Check the combustion chamber and heating surface for soiling
8. Check the supply of the necessary combustion air network
9. Check the exhaust gas routing for function and safety
10. Final inspection check by measuring and documenting the measurement and test results.

9.1 Maintenance and servicing of the burner head HEPM-BH

The intended service life of the burner pad is 20,000 hours of flame operation or five years. This is expressly not a guaranteed service life, but rather the intended period of use as determined by careful engineering rules. Furthermore, use beyond this period is possible if the burner head is in proper working order and no changes in the combustion properties of the burner head are detected during maintenance or operation.

DUNGS recommends maintenance every 4000 hours with flame or at least once a year.

The minimum maintenance requirements are as follows:

1. Check the ignition and ionization electrodes for wear and replace them if necessary according to the replacement instructions in section 9.3.
2. Check the positioning and mounting (firmness and clamping effect) of the ignition and ionization electrodes.
 - a) **Ignition electrode:** Distance to the flame tube approx. 2 mm (see *Figure 10*). This ensures ignition against the flame tube (with secure grounding/earth connection). Ignition against the pad is not permitted.



Figure 10: Positioning of the ignition electrode

- a) **Ionization electrode** (factory preset): must be located in the flame area so that the flame can be reliably detected
7. Visual inspection of the burner pad (corrosion, damaged areas, and highly permeable areas) when the burner is not in operation
8. Visual inspection of the flame pattern (even distribution across the entire pad, no lifting of the flame) during operation
9. Check the burner setting at low, medium, and high load (compare with settings during initial and recommissioning)

Note: Contamination and improper operation

Contamination or improper operation can increase the pressure loss of the burner pad during its service life. This results in reduced burner output for the machine, especially at the upper load points. As part of maintenance, the service technician checks whether the maximum firing capacity is still within an acceptable range for the machine. If this is not the case, the burner pad on spot burner heads can be removed, cleaned with a vacuum cleaner or vacuum device (or compressed air), or replaced.

9.2 Replacement parts for burner heads HEPM-BH

The quantities of all spare parts kits are designed so that five burner heads can be repaired with the contents. Depending on the burner head size, there are minor differences in the spare parts kits and not every spare parts kit is available for every variant. Detailed information on this can be found in the subchapters. The following spare parts kits are generally available:

- Pad and non-return element
- Ignition and ionization electrodes (including screw ring)
- Electrode plug
- Seals

In addition to the spare parts kits, the complete burner heads (scope as per *Module 5*) and the flame tube – with integrated pad and non-return valve – are available as individual spare parts. These are fully assembled and tested.

The exact spare parts and spare parts kits available for each burner head size are described in the following subchapters. To ensure a clear understanding of which spare parts are required, the nomenclature of the burner heads is relevant:




Figure 11: Nomenclature of the burner heads HEPM-BH

The burner heads are installed in ascending order of size in the standard versions of the HeatEngine:

Order no. HeatEngine	Designation HeatEngine	Built-in burner head
294440	HEPM-P025	HEPM-BH-P-D040
294441	HEPM-P040	HEPM-BH-P-D060
294442	HEPM-P060	HEPM-BH-P-D070
294443	HEPM-P090	HEPM-BH-P-D098
294444	HEPM-P140	HEPM-BH-P-D130
294445	HEPM-L025	HEPM-BH-L-E200
294446	HEPM-L065	HEPM-BH-L-E450
304896	HEPM-L140	HEPM-BH-L-E900

Table 5: Mapping between standard HeatEngine and burner head

9.2.1 Point style burner heads up to 40 kW




Figure 12: Structure burner head HEPM-BH-P-D040

Pos	Designation	Repl. Set Pad + FBP	Repl. Set Electr. + Ring	Ers. Set Electr.plug	Ers. Set Gaskets	Ers. Set Flame tube	Ers. Set ... cpl.
10	Burner pad	5					
20	Ring						
30	Flashback protection	5					
40	Retaining ring						
50	Flame tube						
60	Burner housing						
80	Threaded bush						
90	Ignition and Ionization electrode		10				
100	Ignition electrode nut		10				
110	Electrode plug			10			
120	Gasket between burner flange and process chamber				5		
130	Gasket between burner flange and burner adapter				5		
140	Gasket between burner adapter and combustion air fan (not shown, Module 4)				5		
	Order no. HEPM-BH-P-D040	298776	302913	302916	302919	303033	
	Order no. HEPM-BH-P-D060	298777	302913	302916	302919	303034	303351

Table 6: Replacement sets for burner heads D040 and D060

9.2.2 Point style burner head from 60 kW




Figure 13: Structure of burner head HEPM-BH-P-D098

Pos	Designation	Repl. Set Pad + FBP	Repl. Set Electr. + Ring	Ers. Set Electr.plug	Ers. Set Gaskets	Ers. Set Flame tube	Ers. Set ... cpl.
10	Burner pad	5					
20	Ring						
30	Rückschlagsicherung	5					
40	Retaining ring						
50	Flame tube						
60	Burner housing						
70	Intermediate flange						
80	Threaded bush						
90	Ignition and Ionization electrode		10				
100	Screw ring (for D130: Screw/Nut)		10				
110	Electrode plug			10			
120	Gasket between burner flange and process chamber				5		
130	O-Ring on the burner flanges				10		
140	Gasket between burner adapter and combustion air fan (not shown, Module 4)				5		
	Order no. HEPM-BH-P-D070	301655	301656	302916	302920	303035	303352
	Order no. HEPM-BH-P-D098	309033	301656	302916	302920	303036	303353
	Order no. HEPM-BH-P-D130	302912	302914	302917	302921	303037	303354

Table 7: Replacement sets for burner heads D070, D098 and D130

9.2.3 Line style burner heads




Figure 14: Structure of burner head HEPM-BH-L-E200

Independent replacement of the burner pad or flame tube is not permitted for linear burners. Therefore, no spare parts are offered for this purpose. For this reason, the illustration of the linear burner (see Figure 14) shows the exterior view and only depicts the necessary individual parts.

The ignition and ionization electrodes (position 90) on linear burner heads are bent differently. The electrode set therefore contains five straight and five curved electrodes. When installing the electrodes in the burner, ensure that they are used correctly. In addition, the electrodes of the linear burner heads are fastened with a screw and nut (position 100) instead of a screw ring.


Pos	Designation	Repl. Set Electr.	Repl. Set Electr. plug	Ers. Set Gaskets	Ers. Set ... cpl.
10-80	Not shown				
90	Ignition and Ionization electrode	5+5			
100	Screws and nuts	10			
110	Electrode plug		10		
120	Gasket between burner flange and process chamber			5	
130	Gasket between burner flange and burner adapter			5	
140	Gasket between burner adapter and combustion air fan (not shown, Module 4)			5	
	Order no. HEPM-BH-L-E200	302915	302918	302922	303355
	Order no. HEPM-BH-L-E450	302915	302918	302922	303356
	Order no. HEPM-BH-L-E900	302915	302918	302922	303357

Table 8: Replacement sets for burner heads E200, E450 and E900

9.3 Replacement instructions


When replacing and installing the complete burner head, ensure that only the mounting flanges provided for this purpose are used for fastening. Ensure that the burner head is installed without tension.



It is assumed that the HEPM-BH burner head is supplied with a DUNGS MBC-WND WhirlWind system and an MPA as burner control. The fuel/air mixture supply from the DUNGS MBC-WND WhirlWind system must be mounted without tension at the interface of the HEPM-BH burner head. For the US versions, the HEPM-BH units might be installed with a DMV / FRG combination depending on the power consumption.

Note	
	<p>Depending on the burner design and size, the dead weight can range from 0.5 to 100 kg. Use suitable lifting equipment and do not stand under suspended loads.</p> <p>When installing and removing HEPM-BH burner heads, there is a considerable risk of crushing and trapping, depending on the installation location and position. Use suitable tools and the necessary protective equipment.</p>


After successful installation, a leak test is necessary. The leak test can be carried out during operation using foam-forming agents, provided there is sufficient access. If a leak test cannot be carried out after installation due to the design of the machine, it should be carried out prior to installation. In this case, the leak test of the connection points should be carried out at 1.5 times the operating pressure using air as the medium (no fuel/air mixture!).

9.3.1 Replacement of the electrode(s)

Warning	
	<p>Make sure the burner head is cold!</p>




3 Remove the electrode(s) **C** through the hole in the threaded bush **D**.



Note
Pay attention to the bend of the electrode.

The diagram shows a hand holding a white electrode (C) and pulling it out of a hole in a black threaded bush (D) attached to a silver metal component.


4 Insert new electrode **C**.



Note
Do not alter the electrode shape.

The diagram shows a hand inserting a white electrode (C) into the hole of the black threaded bush (D).

5 Tighten the electrode **C** with the electrode nut **B** by hand.




The diagram shows a hand turning a metal electrode nut (B) to secure the electrode (C) in place.

6 Align the electrodes **C**:


- a. The ignition electrode should be positioned as close as possible to the edge of the flame tube, approx. 3-4 mm.
- b. The ionization electrode should be positioned into the flame profile.

7 Tighten the electrode nut(s) **B** with a wrench **12 mm**.



Note
Ensure electrode(s) remain aligned.


8 Reattach the electrode plug(s) **A** by hand.



9.3.2 Replacement of the flame tube


The flame tube, burner pad and flashback protection can only be replaced on point-style burner heads. If the burner pad needs to be replaced on line-style burner heads, the entire burner head must be replaced. Before the flame tube can be removed, the electrodes must be removed in accordance with the previous instructions 9.3.1 (up to step 4) and reattached after replacing the flame tube (from step 5).

Warning




Make sure the burner head is cold!

1 Manually unscrew the flame tube **A** from the threaded bush **B**. If necessary, use a clamping device and pipe wrench.



Warning
The use of a pipe wrench can result in marks!


2 Screw the new flame tube **A** into the threaded bush **B** by hand.







Note
If available, use a strap wrench.


9.3.3 Replacement of the burner pad

The flame tube, burner pad and flashback protection can only be replaced on point-style burner heads. If the burner pad needs to be replaced on line-style burner heads, the entire burner head must be replaced. Before the burner pad can be removed, the electrodes and flame tube should be removed in accordance with the previous instructions 9.2.2 (*up to step 2*), and replaced after the burner pad has been replaced (*from step 3*).


Note	
	Turn the flame tube so that the flashback protection is visible.




5 Insert the ring **D** between the burner pad **E** and the flashback protection **C**.




6 Insert new flashback protection **C** - The sharp-edged side faces inwards.




Note

 The holes in the burner pad **E** and the flashback protection **C** should not be aligned.


7 Lock in position the flashback protection **C** with the snap ring **B**. To do this, reinsert the snap ring as deeply as possible using needle-nose pliers.




Note

 Press the snap ring **B** down along the edge. When correctly seated, the snap ring **B** will engage.

8 Screw in the thread adapter **A** by hand. Wide thread points downwards.



Note

 If present, brush the thread with a little thread paste.

10 Cleaning

If necessary, the burner components, combustion chamber and heating surfaces must be cleaned. Ensure that the burner system is properly switched off before cleaning. The steps to be taken can be found in the maintenance instructions. The relevant cleaning instructions can also be found in the documentation for the individual components.

Regular cleaning is particularly important for the air filter on the combustion air blower. Over time, many particles from the ambient air can accumulate here, clogging the filter and thus severely impairing maximum performance. Ensuring that the cleanest possible ambient air is drawn in guarantees a longer service life for the air filter.

11 Malfunctions

Various faults and error patterns can occur during operation. Known malfunctions and possible causes are listed below. Furthermore, starting difficulties can be remedied under certain circumstances by increasing the starting power.

Failure effect	Possible failures	Proposed solution
No ignition spark during ignition phase	Ignition transformer defective	Replace ignition transformer
	Ignition cable damaged or not properly connected	Establish proper connection with new ignition cable
	Ignition electrode dirty, worn or incorrectly positioned	Control position of the electrode (according documentation) or replace it
No flame formation during ignition phase	No or too little gas	Ensure a constant, adequate gas supply
	Incorrect gas-air-mixture	Adjust the mixing ratio according to the documentation.
Flame termination during ignition phase	Missing flame signal	Replace ionization electrode / UV sensor
	Ionization line damaged or not properly connected	Establish proper connection with new ionization cable
	Ionization electrode dirty, worn or incorrectly positioned possible	Control position of the electrode (according documentation) or replace it
Flame failure during operation	Unstable flame signal	Replace ionization electrode / UV sensor
	Burner low load too low	Increase low load, clean air filter if necessary
	Flame lifts off	Reduce high loads
	Fault in gas supply to the burner	Ensure sufficient, sustainable gas supply

12 Decommissioning and disposal

To decommission, switch off the gas supply and power supply and close the gas ball valve.

Once the intended service life has been reached or when the higher-level machine is decommissioned, the DUNGS HeatEngine® can also be disposed of separately according to the components.

Local guidelines for the disposal of these materials must be observed.

13 Documents and drawings

These instructions include the appendices listed below.

The drawing can be found at the end of the general section of the instructions in the system documentation, and the corresponding documentation is also enclosed for each component of the burner system.

We reserve the right to make changes in the interest of technical progress.

Appendix 1: Modules and possible combinations (poster)	35
Appendix 2: P&ID diagrams	36
Appendix 3: Block diagrams	40
Appendix 3.1: Block diagram 3-point step	40
Appendix 4: Flame pattern catalogue	42
Appendix 4.1: Flame pattern catalogue Point-style	42
Appendix 4.2: Flame pattern catalogue Line-style	46
Appendix 5: Important parameters of the automatic burner control MPA V2 and their standard setting	50

Appendix 1: Modules and possible combinations (poster)

FIRE UP YOUR PROCESS

DUNGS HeatEngine®
Homogeneous heat distribution @ low emissions & high efficiency

First check all general conditions.

Requirements & Conditions	min.	max.
Process chamber pressure	-5 mbar (-2 °WC)	+3 mbar (+1 °WC)
Process temperature	20 °C (70 F)	450 °C (840 F)
Ambient temperature	-15 °C (+5 F)	60 °C (140 F)
Gas inlet pressure	30 mbar / 0.5 psig	65 mbar / 1 psig
Process air flow velocity	2 m/s (6.5 ft/sec)	5 m/s (16 ft/sec)
Burner installation position	all (vertical, horizontal, upside-down)	
Fuel	<ul style="list-style-type: none"> Natural gas H or L LPG, Propane (Butane - 5%) BioGas (on request) < 20 % Hydrogen up to 100% Hydrogen coming soon 	
Emissions @ 17 % O ₂	NO _x < 10 ppm over entire modulating range CO < 13 ppm over entire modulating range (± 5 ppm if turndown is not fully utilized)	

M5
Burner

Burner head M5 selection depending on:

- Capacity (kW/BTU)
- Machine geometry

M4
Connection

Defines the orientation of the burner head/choose:

- Straight
- 90° bend

M3
Blower & mixing unit

Defines the capacity: Selection suitable for the selected burner head

M2
Gas train

Selection according to the burner capacity. Observe suitable flow direction (from left-right or right-left).

M1
Gas connection

Selection according to the planned installation. Customized pipework possible.

M6
Automatic burner control

MPA delivery


- mounted at the DUNGS HeatEngine®
- loosely supplied for control cabinet mounting

M7
Electrical wiring & mounting


Learn more!

Karl Dungs GmbH & Co. KG
 Karl-Dungs-Platz 1
 73660 Urbach, Germany
 Phone: +49 7181-804-0
 info@dungs.com • www.dungs.com


Appendix 2: P&ID diagrams



1 Standard P&ID diagram for ISO 13577-2




2 Standard P&ID diagram for NFPA 86:2023 up to 150 kBTH/H (44 kW)



E				STATE:	12.02.2024
D				ORIGINAL:	Original
C				REPLACED FOR:	
B				REPLACED WITH:	
A	Drawing format A3	2024-02	WMA	DOCUMENT TYPE:	
ISSUE	AMENDMENT	DATE	Name		
DRAWN	2024-01		JB	MATERIAL NO.	
CHECKED					
RELEASED					
STATUS	RELEASED			DOCUMENT NO.	
SCALE	R+I Schema HeatEngine HEPM NFPA 86:2023 150 - 400 kBTH/H				
	DUNGS			VERSION	DOC. PART 001
	ORG1084			REVISION	A SHEETOTAL 1/1

3 Standard P&ID diagram for more than 150 kBTU/H (44 kW)

[https://dungs.sharepoint.com/sites/HeatEngine/Commercialization/Freigegebene_Dokumente/Technik/R+I_Schema_\(P&ID\)/R+I_Schema_HeatEngine_HEPM_NFPA_86:2023_V1_BVsix](https://dungs.sharepoint.com/sites/HeatEngine/Commercialization/Freigegebene_Dokumente/Technik/R+I_Schema_(P&ID)/R+I_Schema_HeatEngine_HEPM_NFPA_86:2023_V1_BVsix)




E				STATE:	12.02.2024
D				ORIGINAL:	Original
C				REPLACED FOR:	
B				REPLACED WITH:	
A	Drawing format A3	2024-02	WMA	DOCUMENT TYPE:	
ISSUE	AMENDMENT	DATE	Name		
DRAWN	2024-01		JB	MATERIAL NO.	
CHECKED					
RELEASED					
STATUS	RELEASED			DOCUMENT NO.	
SCALE	R+I Schema HeatEngine HEPM NFPA 86:2023 >400 kBTH/H				
	DUNGS			VERSION	DOC. PART 001
	ORG1084			REVISION	A SHEETOTAL 1/1

4 Standard P&ID diagram for more than 400 kBTU/H (117 kW)


[https://dungs.sharepoint.com/sites/HeatEngineCommercialization/Freigegebene_Dokumente/Technik/R+I_Schema_\(P&ID\)/R+I_Schema_HeatEngine_HEPM_NFPA_86:2023_POC_Bystr](https://dungs.sharepoint.com/sites/HeatEngineCommercialization/Freigegebene_Dokumente/Technik/R+I_Schema_(P&ID)/R+I_Schema_HeatEngine_HEPM_NFPA_86:2023_POC_Bystr)

Appendix 3: Block diagrams

Appendix 3.1: Block diagram 3-point step



Appendix 3.2: Block diagram Analog control



Appendix 4: Flame pattern catalogue

Appendix 4.1: Flame pattern catalogue Point-style



Point-style **Correct settings**

Minimum power

- Flame burns stationary (without flickering, without movement)
- Pad only glows in isolated places
- No secondary flame fronts
- Individual flame cones visible on pad
- Flame is blue

Maximum Power


- Flame burns stationary (without flickering, without movement)
- Pad does not glow, burner rim glows a little dark red at most
- No secondary flame fronts
- Flame is blue



Point-style **Incorrect settings**


Minimum power too lean!

- Flame flickers
- Flame roots take off
- Flame only faintly visible
- Flame unstable
- Too little fuel gas




Minimum power pad glows!

- Pad glows evenly and continuously
- Min. fan speed too low
- Flame "too stoichiometric", slightly too much fuel gas



Minimum power too rich!


- Flame cones on pad change from blue to turquoise-greenish
- Secondary flame front, wobbling
- Too much fuel gas



Point-style **Incorrect settings**


**Maximum power
too lean!**

- Flame flickers, moves
- Flame partially lifts off
- Flame faint blue
- Too little fuel gas




**Maximum power
too rich!**

- Flame flickers, moves
- Flame partially lifts off
- Flame turquoise-greenish
- Secondary flame fronts far above the flame
- Possibly orange strands
- Too much fuel gas




Point-style ignition sequence **Correct settings**


- 1. Pre-purge (Fan max)
- 2. Fan on ignition power




- 3. Ignition spark + gas on



- 4. Ignition




- 5. Stabilization



Appendix 4.2: Flame pattern catalogue Line-style


Line-style Correct settings

Minimum power



- Flame burns stationary (without flickering, without movement)
- Pad only glows in isolated places
- No secondary flame fronts
- Individual flame cones visible on pad
- Flame is blue


Maximum power



- Flame burns stationary (without flickering, without movement)
- Pad does not glow, burner rim glows a little dark red at most
- No secondary flame fronts
- Flame is blue


Line-style **Incorrect settings**

Minimum power too lean!



- Flame flickers
 - Flame roots take off
 - Flame barely visible
 - Flame unstable
- Too little fuel gas

Minimum power too rich!




- Flame cones on pad change from blue to turquoise-greenish
 - Secondary flame front, wobbling
 - Possibly orange strands
- Too much fuel gas

Line-style **Incorrect settings**


Maximum power too lean!

- Flame flickers, moves
- Flame partially lifts off
- Flame faint blue
- ➔ Too little fuel gas




Maximum power too rich!

- Flame flickers, moves
- Flame partially lifts off
- Flame turquoise-greenish
- Secondary flame fronts far above the flame
- Possibly orange strands
- ➔ Too much fuel gas




Line-style Ignition sequence **Correct settings**


1. Pre-purge (fan max)
2. Fan on ignition position
3. Ignition spark + gas on




4. Local ignition



5. Through ignition line-style burner



6. Stabilization



Appendix 5: Important parameters of the automatic burner control MPA V2 and their standard setting

Parameter-No.	Parameter description	Possible values	Presetting
239	Extension module	0, 1 (= EM installed)	1
<u>General</u>			
10	Release parameter settings***	0 = No, 1 = Yes	0
11	Fieldbus address configuration	0...254 (255 = off)	255
12	Number of restart attempts	0, 1, 2, 3, 4, 5	5
13	Number of restart attempts when flame is missing	0, 1, 2, 3, 4, 5	0
14	Number of restart attempts after flame lift-off	0, 1, 2, 3, 4, 5	0
15	Locking with open safety chain	0 = Restart attempt 1 = Immediate malfunction lockout	1
16	Operating mode for LDW 1	0, 1, 2, ..., 15	13
17	Temperature controller: Operating mode	0, 1, 2, 3, 4	0
18	Input X17	0, 1, 2, 3, ...15	3
19	Configuration of output for operation	0, 1, 2, 3, ... 11	3
20	Safety chain open duration	0...65534 [1/ 16 s] (65535 = infinite)	65535
21	Shutter test for flame detector device	0, 1, 2, 3	0
22	FM mode	0, 1	1
23	POC tolerance time	16...48 (in 1/16 s)	16
26	Input X16	see parameter 18	2
27	Input X18	see parameter 18	9
28	Input X19	see parameter 18	10
29	Input X20	see parameter 18	11
60	Network adress 3	0...255	192
61	Network adress 2	0...255	168
65	Behaviour when waiting for air purge / cooling	0, 1	0
<u>Start-up</u>			
30	Pre-aeration duration	0...32767 [1/16 s]	32767
31	Duration of pre-ignition time	2...65534 [1/16 s]	0
32	Safety time for start-up / first safety time	16...960 [1/16 s]	48
33	Active flame detector device(s) for safety time for start-up	1, 2, 3, 4	1
34	Stabilization time A	0...65534 [1/16 s]	48
35	Second safety time during start-up	16...480 [1/16 s]	16

36	Active flame detector device(s) for phase 2	1, 2, 3, 4	1
37	Stabilization time B	0...65534 [s]	0
38	Operating mode V1 V2	0, 1, 2, ... 5	1
39	Maximum waiting time for start release	0...65534 [1/16 s] (65535 = infinite)	2400
48	Ionization threshold	12...60 [0,1 µA]	12
49	Operating release control	0, 1 (= active)	1
<u>Operation</u>			
40	Duration of normal operation	1...65534 [min] (65535 = infinite)	65535
41	Safety time operation FLW 1	12...48 [1/16 s]	16
42	Safety time operation FLW 2	3...48 [1/16 s]	16
43	Duration for new start of pilot burner	8...960 [1/16 s]	16
<u>Shutdown</u>			
50	Follow-up time	16...65534 [1/16 s]	16
51	Post-purge time	16...65534 [1/16 s]	96
52	Restart protection	16...65534 [1/16 s]	0
<u>Extension module</u>			
25	Maximum waiting time until motor position is reached	0...1920 [1/16 s]	480
240	Pre-aeration position	0...100 [%]	100
241	Ignition position	0...100 [%]	30
242	Stabilization	0...100 [%]	30
243	Post-aeration	0...100 [%]	100
244	Start value	0...100 [%]	25
245	Minimum speed	0...100 [%]	19
246	Maximum speed	0...100 [%]	100
247	Schrittweite Drehzahländerung	0...100 [%]	1
248	Increment for speed changes	0...4095,875 [s]	5
249	Bit functionns	PWM / Analog	PWM

Note: The default setting may differ from customized settings. Please pay attention, in the case of customer-specific parameterization, to the parameter setting supplied.

DUNGS®

Combustion Controls

Karl Dungs GmbH & Co. KG

Karl-Dungs-Platz 1

73660 Urbach, Deutschland

Telefon: +49 7181 804-0

Telefax: +49 7181 804-166

E-Mail: [info\(at\)dungs.com](mailto:info@dungs.com)